



Wiring and Names




Config File Setup



Wiring and Names

XT Extension Cable

Blinkin LED Power



FrontLeft

FrontRight

BackLeft

BackRight

MOTOR ENCODER

UART

RS-485

I2C

DIGITAL

ANALOG

SERVOS

+5V POWER

3-pin JST PH cable

Left Line Sensor

Right Line Sensor

Lights

0

1

2

3

4

5

Config File Setup

